



Varier® Active


1



2



Upholstery Cover Care



This product has been on a journey to reach you.
Before using, please reshape the cover to restore to it's original beauty.
It is normal for the cover to be slightly out of shape whilst in transit.
But if you follow the instructions, all will be well.



Adjust the cover using stroking movements with both hands,
starting from the wrinkle and out to the seam.